

Nordica offer/ order handing explanations:

Outward opening Casement windows.

Windows are viewed from the outside. Arrow is pointing to the handle.

Outward opening [Window Type]

outside view



Projecting Side Hung 90° sash with espagnolette



Outward opening [Window Type] outside view




Top hung projecting sash with espagnolette



Outward opening [Window Type]

outside view



Inward opening Tilt and Turn windows.

Windows are all viewed from the inside. Arrow is pointing to the handle.

Inward opening [Window Type] inside view



Tilt and turn sash



Inward opening [Window Type] inside view



Tilting sash Tilt only (handle on top rail)



Inward opening [Window Type]




Fixed light (direct glazed)

Outward and Inward opening doors.

Doors are viewed from the outside. Arrow is pointing to the handle.


Inward opening [Door Type] outside view





Entrance door with 3 point lock, Right Inwards

Outward opening [Door Type]






Entrance door with 3 point lock, Left Outwards

Folding doors.

Doors are viewed from the opening direction.

Inward opening DK10 window inside view



- Side hung sash
- Slide-fold sash
- Slide-fold sash



Outward opening CENTOR folding door



Outside

- Side hung sash
- Slide-fold sash
- Slide-fold sash




Sliding doors.

Inside

Doors are viewed from the inside.


Inward opening DK10 window inside view



- Parallel tilt and slide window/door (handle left)
- Fixed light



GU lift and slide patio door inside view



- Sliding sash
- Sliding door, fixed sash

